



# OAKSONLINE TOYWATCH

## INSTRUCTION MANUAL

## SETTING TIME & DATE



1. To set the time twist pin one towards you to loosen it. It can be tight so feel free to be quite firm. Turn the pin a few times.
2. You can now pull the pin out from the watch and you should feel a click. The first click is to set the date. Turn to adjust the date
3. Pull again to set the time, you should hear and feel a click. Turn again to change the time.
4. When you have set the time and date press the pin back into place and turn away to tighten the pin into position

## WATCHES WITH CHRONO

1. On watches with Chronographs if you press button two it will start the count in seconds
2. Button three on most models will reset the count back around to 12:00 position

## SETTING TIME & DATE